

## CB007 - INSTALLATION INSTRUCTIONS

### TOOLS:

- Sockets – 15/16"
- Wrenches – 15/16"
- Jack and jack stands

### INSTALLATION:

1. Lift vehicle and support using jack stands under the frame rails.

2. Remove both front wheels and tires.

3. Insert the supplied spacers into the subframe as shown in **IMAGE 1**. Using your finger or a bent piece of wire, slide the spacer back to the mounting hole taking care not to push it too far.

4. Position the brace into place as shown in **IMAGE 2**.

5. Place one of the provided 5/8" washers over the 5/8" x 2.75" bolts. Insert the 5/8" bolts (from the bottom) into the rear mounting holes. Place another washer over the bolt then thread a lock nut onto the bolt. Duplicate for the other side.



6. Tighten the front bolts first. Torque to 184 ft/lbs.

7. Tighten rear bolts to 100 ft/lbs using a 15/16" wrench and socket. (**IMAGE 3**)

8. Re-install wheels/tires and lower vehicle.

[WWW.BMRSUSPENSION.COM](http://WWW.BMRSUSPENSION.COM)

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to vehicle/person during installation or use of this product.