

CB007 - INSTALLATION INSTRUCTIONS

TOOLS:

- Sockets – 15/16"
- Wrenches – 15/16"
- Jack and jack stands

INSTALLATION:

1. Lift vehicle and support using jack stands under the frame rails..
2. Insert the supplied spacers into the subframe as shown in **IMAGE 1**. Using your finger or a bent piece of wire, slide the spacer back to the mounting hole taking care not to push it too far.
3. Position the brace into place as shown in **IMAGE 2**.
4. Place one of the provided 5/8" washers over the 5/8" x 2.75" bolts. Insert the 5/8" bolts (from the bottom) into the rear mounting holes. Place another washer over the bolt then thread a lock nut onto the bolt. Duplicate for the other side.
5. Tighten bolts to 100 ft/lbs using a 15/16" wrench and socket. (**IMAGE 3**)



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to vehicle/person during installation or use of this product.