



SB009 INSTALLATION INSTRUCTIONS

TOOLS REQUIRED:

- Hydraulic jack and jack stands
- 5/8" wrench and socket

Installation Instructions:

1. Raise rear of the car in the air and secure with jack stands.
2. Remove the four (4) bolts holding the rear sway bar to the lower control arms.
3. Install the provided nuts, bolts and washers as shown.
4. Tighten using a 5/8" socket and wrench and torque to 45ftlbs.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicle's manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.