

STB018 – INSTALLATION INSTRUCTIONS

1. Using a 13mm socket, remove all 6 strut tower bolts for both front struts and discard. Make sure wheels are on the ground or supported to prevent the struts from falling out of the locator holes.
2. Place included spacers on all bolt holes
3. Install strut tower brace using the supplied hardware, tightening all bolts to 16 ftlbs.

IMAGE 1



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle/person during installation or use of this product.